



DLUS

DISINFECTANT CLEANER

DIN# 02502755

DESCRIPTION

BACOBAN™ DLUS DISINFECTANT CLEANER is a multi-functional hard surface disinfectant and cleaner that is used wherever superior hygiene is required. Bacoban DLUS helps prevent growth of bacteria, mold, and mildew that can cause stains, odours and deterioration of the surface.

SUITABLE USES

This product can be used in multiple areas and on a variety of hard surfaces in hospital, healthcare facility, domestic, industrial, institutional and food processing settings, such as:

- Laboratory and instrumentation rooms
- Hotels and hospitality settings
- Public restrooms and public spaces
- Recreational facilities
- Schools and campuses
- Household and commercial kitchens
- Windows, stainless steel, ceramic, porcelain, plastic, acrylic, wood and treated surfaces.

FEATURES



Trusted by Hospital and Healthcare Facilities



Meets aviation standards for use inside aircraft (Boeing D6-17487/Boeing D6-7127/AMS 1452B/AMS 1451B)



Approved for food processing use



Water-based and rapidly bio-compatible



Kills 99.99% of viruses, bacteria, and fungi



Will not damage electronic devices or equipment



Contains no Volatile Organic Compounds (VOCs)



SPECIFICATIONS

APPEARANCE:

Colorless- yellow, clear liquid

PH VALUE:

TBD

FORMATS:

- 800 mL spray bottle
- 3.78 L jug

SCENT:

Characteristic of ingredients

SHELF LIFE:

2 years from date of manufacture

MANUFACTURE:

Made in Canada

NOTE: The data presented herein is based on experiments and information believed reliable. However, we can make no guarantee on performance of, or results obtained through the use of the product herein described owing to varying conditions in laboratories and plants over which we have no control. Neither can any guarantee be given that the products or uses outlined will not infringe any existing patents.

USE DIRECTIONS

Pre-clean heavily soiled areas. Spray **BACOBAN™ DLUS DISINFECTANT CLEANER** directly onto the surface. Allow treated surfaces to remain wet for 10 minutes. Wipe surface clean with a microfiber cloth. For surfaces and/or objects that may come into direct contact with children at the mouthing stage of development, a rinse with potable water is recommended.

PRECAUTIONS FOR HOSPITALS AND HEALTHCARE SETTINGS: This product is not to be used as a sterilant/high-level disinfectant on any surface or instrument that: (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to pre-clean or decontaminate critical or semi-critical medical devices prior to sterilization or high-level disinfection.

STORAGE

Store in a dry place no lower in temperature than 10°C or higher than 25°C. Keep out of reach of children. See SDS for full storage and handling information.

RECYCLING

Rinse the emptied container thoroughly. Make the empty container unsuitable for further use. Dispose of the container in accordance with the Provincial Regulatory Agency.

PRODUCT CODE

Format	Liquid spray (800 mL) bottle	Liquid solution (3.78 L jug)
U/M	1 case; 12 per case	1 case; 4 jugs per case
Active Ingredient	0.3057% w/w Benzalkonium chloride	0.3057 % w/w Benzalkonium chloride
Origin of Goods	Canada	Canada
Part #	DLUS-C800	DLUS-C378